



6" FOLD DOWN CLEAT (Part #: DSAFL06)

Materials:

- 6" Fold Down Cleat (1)
- Hardware
 - (2) 3/8" X 1" bolts, washers & nuts
- Tools
 - 9/16" open end wrench
 - (Optional)
 - 9/16" socket wrench, (better)
 - Battery operated impact wrench w/ 9/19" socket (best)

Instructions:

1. Lay out your materials and make sure they are in correct supply (see *Figure 1*).
2. Place head of bolt into track of dock and move to location where you want your cleat (see *Figure 2*). *Bolts can be inserted into track at intermittent access slots along the side of the dock.*
3. Push bolts through holes in cleat (logo should be upside down and cleats hang down against the dock frame) and tighten (see *Figure 3*).
4. You're done, enjoy!



Figure 1



Figure 3



Figure 2

RJ Industries

Mail: P.O. Box 143, Charlton Depot, MA 01509
Plant: 1 Hawksley Road, Oxford, MA 01540