



Torpedo Bumper

Part #: DS18CB

Materials:

- (1) Bumper Bracket (1) Bumper Pad
- (1) Plastic Bracket Cap
- Hardware
 - (2) 3/8" x 1" Bolt, Brass Nylock Nut & Stainless Steel Washer
 - (2) 1/4" x 1" Tek screws
- Tools
 - 9/16" Wrench
 - Battery operated drill or impact wrench

Instructions:

1. Lay out your materials and make sure you have everything in the kit
(see Figure 1).
2. Put the head of the bolt into access slot in the track (approximately in the center along the length of the dock), slide the the bolt in the track towards the corner where you'd like to install bumper.
3. Place the Bumper Bracket on the corner of the frame so the perpendicular flanges hug the sides of the dock. Push the bolt through the cut-out in the aluminum flange, place washer and nut and hand tighten.
4. If the end of your dock has a Trac end (i.e. the same Trac rail as on the side of the frame) then:
 - a. Slide the head of the bolt into the track and move it towards the corner mating with the slot in the Bumper Bracket, install washer and nut and hand tighten.
(see Figure 2).
5. If the end of your dock has a Classic end (a flat aluminum plate), then:
 - a. Screw the 2 self-tapping Tek screws through holes in bumper bracket and into the aluminum Classic End Cap.
(see Figure 3)



Figure 1



Figure 2

RJ Industries

Mail: P.O. Box 143, Charlton Depot, MA 01509
Plant: 1 Hawksley Road, Oxford, MA 01540



Installation Instructions

www.shoresidedocks.com

6. Tighten all nuts and bolts
7. Pull top of Bumper Pad over the top of the Bumper Bracket post
(see Figure 4).
8. Put plastic Bracket Cap on-top of the Bumper Bracket
(see Figure 5).

Enjoy



Figure 3



Figure 4



Figure 5

RJ Industries

Mail: P.O. Box 143, Charlton Depot, MA 01509
Plant: 1 Hawksley Road, Oxford, MA 01540